



WR-MT KIT INSTALLATION

In-Ground Mounting Hardware Instructions:

- 1) To install anchor, drill (not included) $5/8"$ hole into mounting surface at least as deep as the anchor.
- 2) Insert the anchor (threaded side down) into the hole, then tap the anchor until it is flush with the surface.
- 3) Tighten the hex bolt through receptacle base and washer into anchor.

