

COMPONENTS:



2x Locking Casters 2x Non-Locking Casters



4x Locking Washers



4x Wing Nuts






4x Plastic Spacers



4x Metal Plates

PLEASE NOTE:

These casters are compatible with the Cube, Cube Slim & Ellipse Configurations.



- 1 Remove original feet from Spectrum body using a number 2 Phillips Screwdriver.
- 2 Align hole of 1 Metal Plate with the hole on the bottom of the container. See *Figure 1* to ensure you have the correct orientation of the Metal Plate.
- 3 Put the Plastic Spacer on the Caster then thread the Caster into the hole through the Metal Plate.
TIP: Install both Locking Casters towards the front of the container.



- 4 Tighten the Castor using a 5/8" wrench.



- 5 Place Wing Nut on the end of the bolt through the Spectrum Body.



- 6 Repeat Steps 2-5 until you have installed all four Castors

Figure 1

