## Mesa Bench Connector Installation Instructions

## → PRIOR TO INSTALLING YOUR MESA BENCHES ←

## INSTALLATION INSTRUCTIONS MESA BENCH CONNECTOR

<u>STEP 1:</u> LAY 2 SECTIONS OF THE MESA BENCH FLAT ON THE GROUND WITH THE UNDERSIDE FACING UP. ADJUST THE SECTIONS SO THAT THE ENDS ARE FLUSH WITH EACH OTHER.

STEP 2: PLACE THE CONNECTORS FLAT ON THE BENCHES
- ONE TOWARD THE FRONT OF THE BENCHES AND ONE
TOWARD THE BACK (FLIP THE CONNECTORS SO THE END
WITH 2 HOLES ARE ON DIFFERENT BENCHES). MARK THE
CENTER OF EACH HOLE WITH A MARKER.

REF#	QTY	DESCRIPTION
1	2	1-1/2" x 5-1/2" SS CONNECTOR
2	6	3/8" FLAT WASHER
3	6	3/8" x 1-1/4" LAG SCREW

STEP 3: USING 1/8" DRILL BIT, DRILL PILOT HOLES IN BOTH BENCHES AT EACH MARKED SPOTS.

**STEP 4**: USING THE FLAT WASHERS AND 1-1/4" LAG SCREWS, ATTACH THE CONNECTORS TO EACH MESA BENCH ONLY ON THE ENDS WITH THE 2 HOLES (YOU WILL ATTACH THE END WITH THE SINGLE HOLE AFTER YOU'VE COMPLETED YOUR INSTALLATION OF THE BENCHES).

<u>STEP 5</u>: WHEN YOU ARE NEAR THE END OF COMPLETING YOUR INSTALLATION OF THE MESA BENCHES YOU MAY LINE UP THE END OF EACH CONNECTOR WITH THE SINGLE HOLE TO THE PILOT HOLE YOU MADE IN STEP 1. ATTACH THE CONNECTORS TO EACH BENCH USING THE FLAT WASHERS AND 1-1/4" LAG SCREWS.

