



Poly Furniture Care



Clean your poly furniture regularly with non-abrasive soap and water to ensure the continued beauty of your furniture.

Colors like white, gray or ivory and other of our lighter colors will need to be cleaned more frequently to maintain their original beauty. With our lighter colors, spray the furniture with non-abrasive cleaner then wipe with a cloth and rinse off with warm, clean water. We would not recommend using a pressure washer. But if you choose to use one, do not hold the pressure washer too close to the furniture. It may cause the material to tear away so be sure to hold the tip more than 12 inches away from the furniture.

Do not place items on the furniture that will leave a stain. Do not place hot items directly on the furniture. If properly cared for, you will be able to enjoy your poly furniture for many years.