


# 8 Foot Cambridge Park Bench

For Fastener Pack  
(FP-CB8B-CU-01)




Congratulations !!  
You have just purchased the finest recycled plastic  
park bench available. Enjoy !!!

Before assembly, please make sure all components are included.




(1) - One Fastener Pack  
FP-CB8B-CU-01


FP - Fastener Pack




C - Bench End



C - Bench End



C - Bench End



C - Bench End

(4) - Four Bench Ends  
PS-CBBE-A-01

•	•	•	•	•	•
•	•	•	•	•	•
•	•	•	•	•	•
•	•	•	•	•	•

(4) - Four Bull Nose  
Bench Boards  
BP-CB8B-A-01

•	•	B - Bench Board	•	•	•	•
•	•	B - Bench Board	•	•	•	•
•	•	B - Bench Board	•	•	•	•
•	•	B - Bench Board	•	•	•	•
•	•	B - Bench Board	•	•	•	•
•	•	B - Bench Board	•	•	•	•

(6) - Six Bench Boards  
BP-CB8B-B-01

Before assembly, please make sure all fasteners are included.

80 - #12 x 1 1/2" Pan Head Phillips Screw





Also needed for this assembly will be the following materials:

1 - #3 Phillips Drive Bit

**Fig #1:**

In order to make the assembly of this Cambridge Bench easier while going through the assembly process the board positions are numbered and will be referenced in later steps.




**Note:**

Stand bench ends flat on ground. View is only to show detail.

**Step #1:**

Stand (1) One bench end upright and place (1) One bull nose bench board (A) on position 1 being sure to align the pilot holes to the pre-drilled holes in the bench end. After the holes are properly aligned, fasten with (1) One #12 x 1 1/2" Pan Head Phillips Screw in the pre-drilled hole on the right side of the bench end.

Note: Do not tighten screw completely. This will be done in a later step.



**Step #2:**


Stand the other (3) Three bench ends upright, one at a time, and place the bull nose bench board (A) already attached to the first bench end, on position 1 being sure to align the pilot holes with the pre-drilled holes in the bench end. After the holes are properly aligned, fasten with (1) One #12 x 1 1/2" Pan Head Phillips Screw in the pre-drilled hole on the right side of the bench end.

**Note:** Do not tighten screws completely. This will be done in a later step.

**Step #3:**


Align the pilot holes on the bull nose bench board (A) to the pre-drilled holes on the left side of the bench ends. After the holes are properly aligned, fasten with (1) One #12 x 1 1/2" Pan Head Phillips Screw per bench end.

Note: Be sure to tighten screws completely after this step.




**Step #4:**

Place a second bull nose bench board (A) on position 10. Repeat Steps 1 - 3 to attach. Use (1) One #12 x 1 1/2" Pan Head Phillips Screw per hole to fasten.



**Step #5:**

Repeat Steps 1 - 3 to attach bull nose bench boards (A) on positions 4 & 5.  
Use (1) One #12 x 1 1/2" Pan Head Phillips Screw per hole to fasten.



**Step #6:**

Repeat Steps 1 - 3 to attach bench boards (B) on positions 2, 3, 6, 7, 8 & 9.  
Use (1) One #12 x 1 1/2" Pan Head Phillips Screw per hole to fasten.