


6 Foot Traditional ADA Park Bench

For Fastener Pack
(FP-TB6HA-CU-01)



Congratulations !!


You have just purchased the finest recycled plastic
park bench available. Enjoy !!!

Before assembly, please make sure all components are included.



(1) - One Fastener Pack
FP-TB6HA-CU-01


FP - Fastener Pack




D - Bench Arm

D - Bench Arm


(2) - Two Bench Arms
BP-BA-HA-01



B - Bench End




B - Bench End




B - Bench End

(3) - Three Bench Ends
PS-SBBE-H-01


G - Mounting Plate




G - Mounting Plate



G - Mounting Plate




(3) - Three Mounting Plates
BP-TBHA-A-01




H - Bench Board

(1) - One Bench Board
BP-TB6HA-A-01




E - Bench Board

(1) - One Bench Board
BP-TB6HA-B-01



F - Bench Board

(1) - One Bench Board
BP-TB6HA-C-01



A - Bench Board

(1) - One Bench Board
BP-TB6B-A-02



C- Bench Board w/ Arm holes

(1) - One Bench Board
BP-TB6BA-A-02

FS-TB6HA-CAP-01

Before assembly, please make sure all fasteners are included.

22 - #12 x 3" Flat Head Phillips Screw



15 - #12 x 2" Flat Head Phillips Screw



24 - #12 x 2" Pan Head Phillips Screw



Also needed for this assembly will be the following materials:

1 - #3 Phillips Drive Bit





Fig #1:


In order to make the assembly of this Traditional Bench easier while going through the assembly process the board positions are numbered and will be referenced in later steps.



Step #1:

Stand (1) One bench end upright and place (1) One "H" bench board on position 1 being sure to align the pre-drilled holes to the pilot holes in the bench end. After the holes are properly aligned, fasten with (1) One #12 x 3" Flat Head Phillips Screw in the top pre-drilled hole.

Note: Do not tighten screw completely. This will be done in a later step.



Step #2:


Stand the other (2) Two bench ends upright, one at a time, and place the bench board already attached to the first bench end, on position 1 being sure to align the pre-drilled holes to the pilot holes in the bench end. After the holes are properly aligned, fasten with (1) One #12 x 3" Flat Head Phillips Screw in the top pre-drilled hole.

Note: Do not tighten screws completely. This will be done in a later step.

Step #3:


Align bottom pre-drilled holes to the pilot holes in the bench end. After the holes are properly aligned, fasten with (1) One #12 x 3" Flat Head Phillips Screw per hole.

Note: Be sure to tighten screws completely after this step.




Step #4:

Place a Mounting Plate with the countersink's facing up on each bench end. Being sure to align the pre-drilled holes to the pilot holes in the bench end. Use (1) One #12 x 2" Flat Head Phillips Screw per hole to fasten.




Step #5:

Repeat Steps 1 - 3 to attach bench board A on position 3 and a bench board w/ arm holes C on position 2. Use (1) One #12 x 3" Flat Head Phillips Screw per hole to fasten.



Step #6:

Attach bench board E on position 4 and a bench board w/ arm holes F on position 5. Being sure to align the pre-drilled holes in the mounting plates to the pilot holes in the bench boards. Use (1) One #12 x 2" Pan Head Phillips Screw per hole to fasten.



Step #7:

Position the bench arms as shown above. align the pilot holes to the pre-drilled holes in the bench board w/ arm holes. After the holes are properly aligned, Fasten (1) One #12 x3" Flat Head Phillips Screw per hole.